


DIGITAL MULTIMETER



Before using the instrument, please read this manual carefully, and save it well for future using.

Statement... 1
Safety Statement... 1
Safety Instructions... 2
Safety Operation Specifications... 2
Safety Symbols... 6
Overview... 6
Instrument panel description... 6
FUNC. keys... 7
Data hold... 7
Maximum measurement... 7
Backlight... 7
Flashlight... 8
Auto power off... 8
Input LED indication function... 8
High voltage prompt function... 8
Measurement operation... 9
DC/AC voltage measurement... 9
Frequency/Duty measurement... 10
DC/AC current measurement... 11
Resistance measurement... 12
Continuity measurement... 12
Diode measurement... 13
Capacitance measurement... 13
NCV test... 14

Live test... 15
Battery test... 15
Temperature Measurement (Optional)... 16
General Technical Specifications... 17
Accuracy Specifications... 18
DC voltage... 18
AC voltage... 18
DC current... 19
AC current... 19
Resistance... 20
Capacitance... 20
Frequency/Duty... 21
Diode test... 22
Continuity test... 22
Temperature (Optional)... 22
Maintenance... 23
Clean... 23
Replace Battery and Fuse... 23

Statement
In accordance with the international copyright law, without permission and written consent, do not copy the contents of this manual in any form (including storage and retrieval or translation into languages of other countries or regions). The manual is subject to change in future edition without prior notice.
Safety Statement
Caution mark refers to the condition and operation which may cause damage to the instrument or equipment. It requires that you must be careful during the execution of the operation. If incorrectly perform the operation or do not follow the procedure, it may damage the instrument or equipment. In the circumstances that such conditions are not met or not fully understood, please do not continue to perform any operation indicated by the caution mark.
Warning mark indicates the condition and operation which may cause danger to users. It requires that you must pay attention during the execution of this operation. If incorrectly perform the operation or do not follow the procedure, it may result in personal injury or casualties. In the circumstances that such conditions are not met or not fully understood, please do not continue to perform any operation indicated by the warning mark.

Safety Instructions
The instrument is designed according to the requirements of the international electrical safety standard IEC61010-1 for the safety requirements of the electronic testing instruments. The design and manufacture of instruments strictly comply with the requirements of IEC61010-1 CAT.III 1000V over voltage safety standards and pollution level 2.
Safety Operation Specifications
Warning
In order to avoid possible electric shock or personal injury and other safety accidents, please abide by the following specifications:
Please read this manual carefully before using the instrument, and pay special attention to safety warning information.
Strictly observe the operation of this manual and use this instrument. Otherwise, the protection function of the instrument may be damaged or weakened.
Please be careful if the measurement exceeds 30V AC true RMS, 42V AC peak or 60V DC. There may be danger of electric shock at this kind of voltage.
By measuring the known voltage to check whether the meter work is normal, if it is not normal or damaged, do not use it again.

Before using the instrument, please check whether there is any crack or plastic damage in the instrument case. If you do, do not use it again.
Before using the instrument, please check whether the probe is cracked or damaged. If so, please replace the same type and the same electrical specifications.
The instrument shall be used in accordance with the specified measurement category, voltage or current rating.
Please comply with local and national safety code. Wear personal protection equipment (such as approved rubber gloves, masks and flame retardant clothes, etc.) to prevent being damaged by electric shock and electric arc due to exposed hazardous live conductor.
When it shows low battery indicator, please replace the battery in time in case of any measurement error.
Do not use the instrument around explosive gas, steam or in wet environment.
When using the probe, please put your fingers behind the finger protector of the probe.
When measuring, please connect the zero line or the ground line firstly, then connect the live wire; but when disconnecting, please disconnect the live wire firstly, then disconnect the zero line and ground line.
Before opening the outer cabinet or battery cover, please

remove the probe on the instrument. Do not use the instrument in the circumstances that the instrument is taken apart or battery cover is opened.
It only meets the safety standards when the instrument is used together with the supplied probe. If the probe is damaged and needs to replace, the probe with same model number and same electrical specifications must be used for replacement.

Table with safety symbols: High voltage warning, AC (Alternating current), DC (Direct current), AC or DC, Warning, important safety signs, Ground, Fuse, Equipment with double insulation/reinforced insulation protection, Battery under voltage, Product complies with all relevant European laws, The additional product label shows that do not discard this electrical/electronic product into household garbage, Class II measurements are suitable for testing and measuring circuits directly connected to power points (sockets and similar) of low voltage power installations, Class III measurement is suitable for testing and measuring circuits connected to the distribution part of low voltage power supply devices in buildings, Class IV measurements are suitable for testing and measuring circuits connected to the power supply of low voltage power installations in buildings.

Safety Symbols
Overview
A new generation of high performance digital multimeter. The new display and function layout show clearer and better user experience. It is the best choice for professional electricians, enthusiasts or families.
Instrument panel description
1 NCV probe
2 Flashlight
3 Red / green light
4 LCD display (Dual color backlight)

Function keys
5 Function keys
6 Function knob
7 Other measurement input socket
8 COM Input socket
9 mA, uA Input socket
10 10A Input socket
FUNC. keys
When there are multiple measuring functions on a gear, the FUNC. key switch function is adopted.
Data hold
Press"HOLD" key, enter data hold mode/cancel data hold mode.
Maximum measurement
Press the MAX/MIN key to enter the maximum measurement, and then press the loop to display the maximum and minimum values. Press and hold for more than 2 seconds to cancel the maximum/minimum measurement mode.
Backlight
Press key, turn on backlight/turn off backlight. or about

10 seconds after it will automatically shut down.
Flashlight
Press key, and keep more than 2 seconds to turn on the flashlight / turn off flashlight.
Auto power off
If you press the "FUNC." button and turn on the meter power, the automatic shutdown function will be cancelled. After turning off the meter, the meter is reopened to restore the automatic shutdown function.
Input LED indication function
When power on or function switching, the corresponding input light flashes to prompt the user to insert the input port of the probe.
High voltage prompt function
When the measuring voltage is greater than 80V or the

measuring current is greater than 1A, the orange backlight will light up, prompting the users to be careful.
Measurement operation
DC/AC voltage measurement
1) Turn the knob to "V~" or "V-" and Select the appropriate range
2) Insert the red probe in "V~" socket. Insert the black probe in "COM" socket.
3) Contact the probe to the measured circuit (connect to the measured power or circuit in parallel), measure the voltage.
4) Read the measurement result on the screen, when measuring AC voltage the frequency is displayed on LCD simultaneously.
WARNING
The voltage above DC1000V or AC750V can't be measured; otherwise the instrument may be damaged.
Pay special attention to safety when measuring high voltage to avoid electric shock or personal injury.
Test the known voltage with the meter before use, confirm the instrument function is intact.
Caution:
To avoid damaging instruments or equipment, do not enter frequency or duty cycle signal greater than 10V valid value.
Note 2: when measuring the AC voltage, press the FUNC. key to check the frequency.

Frequency/Duty measurement
1) Turn the knob to "Hz%" and Switching Frequency or duty function by "FUNC." key
2) Insert the red probe in "Hz%" socket. Insert the black probe in "COM" socket.
3) Contact the probe to the measured circuit (connect to the measured power or circuit in parallel), measure the frequency and duty.
4) Read the measurement result on the screen.
WARNING
The voltage above 10V can't be measured; otherwise the instrument may be damaged.
Pay special attention to safety when measuring high voltage to avoid electric shock or personal injury.
Test the known voltage with the meter before use, confirm the instrument function is intact.
Caution:
To avoid damaging instruments or equipment, do not enter frequency or duty cycle signal greater than 10V valid value.

DC/AC current measurement
1) Turn the knob to "mA" or "A" and Select the appropriate range
2) Insert the red probe in "mA" socket or "10A" Socket. Insert the black probe in "COM" socket.
3) Disconnect the power of the tested circuit; connect the meter to the circuit under test, then turn on the circuit power supply.
1) Read the measurement result on the screen. When measuring AC current, the frequency is displayed on LCD simultaneously.
WARNING
The voltage above 250V can't be measured; otherwise the instrument may be damaged.
Pay special attention to safety when measuring high voltage to avoid electric shock or personal injury.
Test the known current with the meter before use; confirm the instrument function is intact.
When measuring large current, continuous measurement should be no longer than 15 seconds
Caution:
To avoid damaging the instrument or equipment, check the fuse before measuring and ensure that the

measured current does not exceed the rated maximum current; use the correct input.
Note:
When measuring AC current, press the FUNC. key to check the frequency.
Resistance measurement
1) Turn the knob to "Ω" and Select the appropriate range
2) Insert the red probe in "Ω" socket. Insert the black probe in "COM" socket.
3) Contact the probe to the measured circuit or resistance, measure the resistance.
4) Read the measurement result.
WARNING
When measuring resistance on the line, disconnect the power supply and discharge all the high-voltage capacitors. Otherwise, the instrument may be damaged and may be struck by electric shocks.
Continuity measurement
1) Turn the knob to "diode"
2) Insert the red probe in "diode" socket. Insert the black probe in "COM" socket.
3) Contact the probe to the measured circuit or resistance.
4) If the resistance or circuit of the measured resistance is less

than 30Ω, the buzzer will on and the green indicator lights up at the same time; when the resistance is about between 30Ω to 60Ω, the red indicator lights up; LCD displays the resistance.
WARNING
When measuring Continuity on the line, disconnect the power supply and discharge all the high-voltage capacitors. Otherwise, the instrument may be damaged and may be struck by electric shocks.
Diode measurement
1) Turn the knob to "diode"
2) Insert the red probe in "diode" socket. Insert the black probe in "COM" socket.
3) Touch the diode anode with the red probe, the black probe contacts the diode cathode.
4) Read the measurement result on the screen.
WARNING
When measuring diode on the line, disconnect the power supply and discharge all the high-voltage capacitors. Otherwise, the instrument may be damaged and may be struck by electric shocks.
Capacitance measurement
1) Turn the knob to "F"
2) Insert the red probe in "F" socket. Insert the black

probe in "COM" socket.
3) Contact the probe to the measured circuit or Capacitance, measure the resistance.
4) Read the measurement result on the screen.
WARNING
When measuring Capacitance on the line, disconnect the power supply and discharge all the high-voltage capacitors. Otherwise, the instrument may be damaged and may be struck by electric shocks.
NCV test
1) Turn the knob to "NCV" and Switch to NCV test function by "FUNC." key. Meter will display "NCV".
2) Then NCV probe gradually approaches the detected point.
3) When the meter senses weak AC signals, the green indicator lights up, at the same time, the beeps send out slow dips.
4) When the meter senses strong AC signals, the red indicator lights up, at the same time, the beeps send out fast dips.
WARNING
In order to avoid possible accidents such as electric shock or personal injury, please follow the safety regulations.
Battery test
1) Turn the knob to battery test shift and select the appropriate range.
2) Insert the red probe in "mA" socket. Insert the black probe in "COM" socket.
3) contacts the positive with the red probe, the black probe contacts the negative.
4) Read the measurement result on the screen.
Note: 1.5V range Load resistance: 30Ω

Live test
1) Turn the knob to the "Live" and Switch to live test function by "FUNC." key. Meter will display "LIVE".
2) Insert the red probe in "Live" socket. Then the probe contact to the test point
3) When the meter senses weak AC signals, the green indicator lights up, at the same time, the beeps send out slow dips.
4) When the meter senses strong AC signals, the red indicator lights up, at the same time, the beeps send out fast dips.
WARNING
In order to avoid possible accidents such as electric shock or personal injury, please follow the safety regulations.
Temperature Measurement (Optional)
9V range Load resistance: 300Ω
1) Turn the knob to the "T".
2) Insert the K thermocouple into the instrument. The thermocouple's positive (red) is inserted into the "T+" input, and the negative end (black) is inserted into the "COM" input.
3) Contact the measured object with the thermocouple probe and read the result from the display.
Note 1:
The cold junction of thermocouple is placed inside the instrument, and it needs longer heat balance with the measuring environment.
Note 2: Using K type thermocouple probe.
WARNING
When measuring temperature with thermocouple, the probe of thermocouple can't touch the charged object, otherwise it may damage the instrument and may suffer electric shock or personal injury.

General Technical Specifications
Environment condition of using:
CAT. IV 600V; CAT. III 1000V;
Pollution level 2, Altitude < 2000m
Working environment temperature and humidity:
0~40°C (<80% RH, <10°C non condensing)
Storage environment temperature and humidity:
-10~60°C (<70% RH, remove the battery)
Temperature coefficient: 0.1% accuracy /°C (<18°C or >28°C)
MAX. Voltage between terminals and earth ground:
DC1000V/AC750V
Fuse protection:
mA: F600mA/250V fuse
10A: F10A/250V fuse
Sampling rate: about 3 times/second.
Display: 6000 counter readout. Automatically display the unit symbols according to the shift of the measurement function.
Over range indication: it displays "OL".
Low battery indication: when the battery voltage is lower than the normal working voltage, "BAT" will be displayed.
Input polarity indication: automatically display "-".
Power requirement: 2 x 1.5V AAA batteries.

Accuracy Specifications
The accuracy applies within one year after the calibration. Reference condition: the environment temperature 18°C to 28°C, the relative humidity is no more than 80%, accuracy: ± (% reading + word)
DC voltage
Range Resolution Accuracy
600mV 0.1mV
6V 0.001V
60V 0.01V ±(0.5% reading+3)
600V 0.1V
1000V 1V
Input impedance: 10MΩ; Maximum input voltage: 1000V DC Overload protection: 1000V DC or 750V AC;
AC voltage
Range Resolution Accuracy
6V 0.001V
60V 0.01V ±(0.8% reading+5)
600V 0.1V
750V 1V
Input impedance: 10MΩ; Maximum input voltage: 750V AC Overload protection: 1000V DC or 750V AC; Frequency Response: 10Hz ~ 1kHz; True-RMS

To avoid possible electric shock, personal injury or instrument damage, please use the fuse with same specifications or specified specifications.

DC current table with columns: Range, Resolution, Accuracy. Values include 600uA, 60mA, 600mA, 10A and their respective resolutions and accuracies.

Resistance table with columns: Range, Resolution, Accuracy. Values include 600Ω, 6kΩ, 60kΩ, 600kΩ, 6MΩ, 60MΩ and their respective resolutions and accuracies.

Frequency/Duty table with columns: Range, Resolution, Accuracy. Values include 10Hz, 100Hz, 1000Hz, 10kHz, 100kHz, 1000kHz, 10MHz and their respective resolutions and accuracies.

Diode test table with columns: Function, Forward DC current is about 2.5mA, Reverse DC voltage is about 3V, Overload protection: 250V.

Continuity test table with columns: Function, Reverse DC voltage is about 3V, Overload protection: 250V.

Temperature (Optional) table with columns: Range, Resolution, Accuracy. Values include temperature ranges and their accuracies.

Maintenance
Clean
If there's dust on the terminal or the terminal is wet, it may cause measurement error. Please clean the instrument according to the steps below:
1) Switch off the power supply of the instrument, and remove the test probe.
2) Turn over the instrument and shake out the dust accumulated in the input socket. Wipe the outer cabinet with a damp cloth and mild detergent; do not use abrasive or solvent. Wipe contacts in each input socket with a clean cotton swab soaked in alcohol.
WARNING
Please always keep the inside of the instrument clean and dry to avoid electric shock or instrument damage.
Replace Battery and Fuse
Replace Battery:
1) Turn off the power supply of the instrument, and remove the probe on the instrument.
2) Use screwdriver to unscrew screws fixing the battery cover, remove the battery cover.
3) Remove old batteries, replace with new batteries of the same specifications. Please note the polarity of the battery according to the positive and negative polarity marks inside of the battery cover.
4) Install the battery cover to its original position, fix and lock